

TECHNICAL BULLETIN

ASPHALT SURFACE PREPARATION

APPLICATION PROCEDURE

Asphalt Surface Preparation

New asphalt should be allowed to oxidise and cure for a minimum of 14-21 days, dependent on climatic conditions.

Asphalt shall be free from all dust, dirt, grease etc. The surface should be cleared by high pressure water blasting and is to be thoroughly dry before application of the **Rebound Ace Sports Surfaces System**.

Cracks, Saw Cuts, Expansion Joints

Structural Cracks (1-3mm)	-	"V" out and fill with a proprietary polyurethane sealant .
Hairline Cracks (less than 1mm)	-	No repair necessary before resurfacing.
Expansion Joints and Saw Cuts (above 3mm to 30mm)	-	Thoroughly clean of dust, dirt etc and fill with proprietary polyurethane sealant. Allow sealant to cure as per manufacturer's directions before application of the Rebound Ace Sports Surfaces System .