

REBOUND ACE® FLEXIBLE FILLER COAT

APPLICATION PROCEDURE

Suitable for use in all
Rebound Ace cushioned mat and Liquid Rubber systems
(not suitable for Impact systems)

DESCRIPTION:

Rebound Ace Flexible Filler Coat is a specially formulated Filler Coat with inbuilt flexibility and high fibre reinforcing. It is designed for use in Rebound Ace cushioned mat and liquid rubber systems. **DO NOT USE** directly on non water-based polyurethane mat sealers without a Tycoat layer.

N.B. Certain types of shoes can cause delamination of the Mat Sealer WB due to the residual tack of the Mat Sealer WB / Tycoat. The wearing of socks only is recommended in lieu of shoes.

Immediately prior to application, ensure surface is thoroughly swept to remove all dirt, dust, etc. Do not apply when surface temperature is below 5°C.

COVERAGE:

(REBOUND ACE GS8mm)

Apply **Rebound Ace® Flexible Filler Coat** direct from the container or (in hot or dry conditions) dilute up to 3 litres of potable water per 20 litres **Rebound Ace® Flexible Filler Coat**. Apply lengthwise of court at a total rate of 0.7 litres/m² in two coats to level surface (based on undiluted material).

(REBOUND ACE HSA CLUB)

Apply **Rebound Ace® Flexible Filler Coat** direct from the container or (in hot or dry conditions) dilute up to 3 litres of potable water per 20 litres **Rebound Ace® Flexible Filler Coat**. Apply lengthwise of court at a total rate of 0.45 litres/m² in two coats to level surface (based on undiluted material).

REBOUND PRO INTERNATIONAL and PREMIUM

Apply **Rebound Ace® Flexible Filler Coat** direct from the container or (in hot or dry conditions) dilute up to 3 litres of potable water per 20 litres **Rebound Ace® Flexible Filler Coat**. Apply lengthwise of court at a total rate of 0.7 – 0.8 litres/m² in two coats (dependant on surface at Applicator's discretion) to level surface (based on undiluted material).

CURE

Allow to cure for a minimum of 4 hours depending on ambient weather conditions. Sand surface if necessary using a circular floor sander to remove any lumps, ridges, or nibs (on first coat only). Sweep surface thoroughly to remove all dust, grindings etc., before application of second Filler Coat and subsequent Rebound Topcoat.