

**REBOUND ACE GS 8mm**

**INSTALLATION SCHEDULE GUIDE**

PROCESS	No. of Men for Process	No. of Days for Process (including curing)				
		1 Court	2 Courts	3 Courts	4 Courts	6 Courts
1. Site set up/surface preparation	5	1	2	2	3	4
2. Adhesive/base mat	5	0.5	2	3	4	6
3. 1st Mat Sealer	5	0.5				
4. 2nd Mat Sealer	3	0.5	2	2	3	4
5. Polyvac Sand/Vacuum	3	0.5				
6. Tycoat/Fibreglass	5	1	2	3	4	6
7. 1st Filler Coat	3	0.5	1	2	2	3
8. 2nd Filler Coat	3	0.5				
9. Sand/Grind ridges	3	0.5	1	1	1	2
10. 3rd Filler Coat (if necessary)	3	0.5				
11. 1st Topcoat play area	3	0.5	1	2	2	3
12. 2nd Topcoat play area	3	0.5				
13. 1st Topcoat surround	3	1	2	2	3	3
14. 2nd Topcoat surround	3	1				
15. Linemarking	3	0.5	1	2	2	3
16. Site Cleanup (progressive)	3	0.5				
<b>Sub Total days</b>		<b>10</b>	<b>14</b>	<b>19</b>	<b>24</b>	<b>34</b>
<b>Number of man days</b>		<b>36</b>	<b>54</b>	<b>73</b>	<b>94</b>	<b>134</b>
<b>25% bad weather allowance</b>		<b>9</b>	<b>14</b>	<b>18</b>	<b>24</b>	<b>34</b>
<b>Total man days</b>		<b>45</b>	<b>68</b>	<b>91</b>	<b>118</b>	<b>168</b>

